

New Frontier ARMORY

AR STYLE FIREARMS

OWNER'S MANUAL:

OPERATION, HANDLING, DISASSEMBLY / REASSEMBLY
& SAFETY INSTRUCTIONS

- DO NOT DISCARD THIS MANUAL - READ THIS MANUAL CAREFULLY, PAYING CLOSE ATTENTION TO THE INSTRUCTIONS AND WARNINGS BEFORE USING THIS FIREARM.

This manual should stay with this firearm at all times. If the firearm is given, transferred or sold to another person, this manual should go with it.

Before loading, using or disassembling this firearm, please **Read, Understand, and Follow all of the instructions and warnings in this manual.**



Caution: If you are unfamiliar with firearms, seek further advice through a NRA Approved Instructor, Gun Safety Training Organization, or similar qualified organizations prior to using this firearm.



Warning: Like any firearm, if this firearm is carelessly or improperly handled, unintentional discharge can result and can cause damage to property, severe injury or even death.



Warning: If this firearm is jarred or dropped with the bolt carrier assembly locked to the rear, or in its forward position with a loaded magazine in place **a round could be chambered.**



Caution: Only clean, dry, high quality commercially manufactured ammunition should be used in this firearm. Only use ammunition that is appropriate for the caliber and design of your firearm.



IMPORTANT NOTICE: Any modifications of any kind, including any addition or removal of components or disassembly beyond what is detailed in the owners manual could completely **VOID YOUR WARRANTY!**

Thank You for Your Purchase

The instructions and safety warnings in this manual are very important. By taking precautions and understanding the dangers associated with the use of any firearm you can enjoy the use of your New Frontier Armory firearm for years to come. Failure to take precautions and follow instructions may result in severe damage to property and/or the firearm as well as serious injury or even death to you or others.


Note: For information or details not covered in this manual, contact tech support at:
www.newfrontierarmory.com/warranty

Table of Contents




Safe Handling: Fundamental Rules & Procedures	4
Getting Ready to Shoot	6
Immediate Action	7
Remedial Action	8
Bullet Stuck in Bore	9
Disassembly of Your Firearm	10
Cleaning Procedures	12
Disassembly of Bolt Carrier	14
Inspection	15
Lubrication of Parts	16
Troubleshooting	17

Fundamental Rules and Procedures for Safe Firearms Handling

- **Always** treat every firearm as if it were loaded.
- **Always** keep every firearm pointed in a safe direction.
- **Always** be sure of your target and what's beyond it.
- **Always** wear eye & ear protection when you or others are shooting.
- **Always** be sure the barrel is clear of obstructions before shooting.
- **Always** carry your gun so that you can control the direction of the muzzle even if you stumble or fall.
- **Never** load a firearm until you are ready to shoot.
- **Never** leave a firearm unattended.
- **Never** store your guns and ammunition together, they should always be stored and secured separately, out of reach of children and anyone unfamiliar with firearms.
- **Never** allow your firearm to be used by anyone who has not read the safe handling and operating instructions.
- **Never** point any gun at anything you do not intend to shoot, whether it is loaded or unloaded.
- **Never** touch the barrel after firing, more than likely it will be very hot.

- Keep your finger off the trigger and leave the safety on until you are ready to shoot! 
- If your firearm fails to fire with a live round still in the chamber (a misfire), remove the round quickly, keeping your face clear of the ejection port. If you are unable to remove the round within 10 seconds, remove the magazine, point the firearm in a safe direction and wait 15 minutes. With the live round still in the chamber, the firearm may still fire the round.
- Do not fire the firearm if there is water in the barrel.
- If there is a noticeable difference in sound or recoil; stop firing immediately! This could indicate there was an incomplete powder burn and/or there is a bullet stuck in the bore.
- If you firearm fires more than one round with the single pull of the trigger, please contact the warranty department immediately.

Getting Ready to Shoot

- With the muzzle pointed in a safe direction, insert a loaded magazine into the magazine well.
- Move the safety lever to the safe position. A rectangular icon showing a safety lever with a diagonal line across it, indicating the safe position.
- Pull the charging handle fully to the rear.
- Release the charging handle. Do not ride or push the charging handle.
- Move the safety lever to the fire position. A rectangular icon showing a safety lever with a horizontal line across it, indicating the fire position.
- **Note:** If the firearm is not going to be fired immediately, make sure the selector lever is set to **safe**. A rectangular icon showing a safety lever with a diagonal line across it, indicating the safe position.

Immediate Action in Case of Trouble

If your firearm stops firing
perform the following immediate actions...

1. Remove the magazine from the magazine well.
2. Pull charging handle all the way back.
3. Inspect the chamber and look for any obstruction or un-fired round. If the chamber is clear and there is not an un-fired round present, proceed to step 4. If the chamber is not clear or if there is an un-fired round in the chamber, stop now and proceed to the “Remedial Action Section”.
4. Re-insert the magazine and make sure it seats properly.
5. Pull the charging handle all the way back and RELEASE to feed a new round. Don't ride the charging handle forward.
6. Pull trigger to fire. If the firearm still will not fire, look for trouble, repeat steps 1-5 and then move to the “Remedial Action” section.

Remedial Action


If your firearm stops firing with a live round in the chamber of a **hot barrel**, remove the round within one second. If it is not possible to remove the round within 10 seconds, remove the magazine, place the selector to SAFE and wait 16 minutes with firearm pointing in a safe direction. This will help prevent injury if a round fires as a result of “Cooking Off” (in a hot barrel). Always remember to keep your face clear of the ejection port while clearing a hot chamber:

- **If** your firearm still fails to fire after performing Steps 1 through 5 on the previous page, check the chamber again for a jammed cartridge case.
- **If** a cartridge case is jammed in the chamber, remove the magazine, pointing the firearm in a safe direction, open the receivers, remove the bolt carrier and try to tap out the case with a cleaning rod from the muzzle end of the barrel.
- **If** your firearm fails to fire, check the “Troubleshooting” section of this manual, or take the firearm to a qualified gunsmith.

Bullet Stuck In The Bore

WARNING:

If you hear an audible “POP” or experience reduced recoil during firing, IMMEDIATELY CEASE FIRE, then:

- Remove the magazine from the firearm.
- Lock the bolt to the rear.
- Place the selector lever on SAFE. 
- Check for a bullet stuck in the bore.

If there is a bullet stuck in the bore DO NOT APPLY the “Immediate Actions” previously described.

If a bullet is stuck in the barrel of the firearm, **do not try to remove it**. Take the firearm to a qualified gunsmith for repair.

Disassembly Of Your Firearm

- Make sure the firearm is not loaded and that it is pointed in a safe direction.
- Remove magazine and verify the chamber is clear.
- Open the bolt by pulling the charging handle completely to the rear, hold the charging handle in this position, lock the bolt in the rearward position by pushing the lower end of the bolt catch lever with your other hand.

ATTENTION: Look into the chamber from the ejection port and visually confirm that there is NOT a round in the chamber.

- Now that you are sure the firearm does not have a round in the chamber, you may proceed with the assembly.
- Release the catch and send the bolt forward.
- Push the rear takedown pin from the left side to release, now pull the pin to its stop detent from the right.
- Grasp the pistol grip with your right hand and the upper receiver with your left hand and separate the rear of the upper receiver from the rear of the lower receiver until the upper pivots open to a 90-degree angle. There may be some resistance because of the tight tolerances between assemblies, especially when dirty.

Disassembly Of Your Firearm

- Pull the charging handle out of the upper and remove both the BCG and the charging handle and place somewhere safe.

ATTENTION: Do not dry fire the firearm (cock hammer and pull trigger) without the upper receiver assembly installed. Doing so could seriously damage the fire control group.

Cleaning Procedures

Clean the Bore

- Always clean from chamber to muzzle in the direction the bullet travels.
- Attach a bore brush to an appropriate length cleaning rod leaving it slightly loose to allow the brush to turn in the bore.
- Never dip the brush in solvent or run a brush down the barrel first.
- Swab out the bore with a patch moistened with high quality bore cleaning solvent.
- Pointing the muzzle down, and the handle removed from your cleaning rod. Hold the upper receiver in one hand while inserting the end of the rod without the brush into the chamber. Be careful not to scratch the bore.
- Attach the handle on your cleaning rod end sticking out of the muzzle.
- Pull the brush through the bore and out the muzzle. The rod should be twisting as you pull it out, this is the brush “tracking” in the rifling. Do not reverse the brush in the chamber.

Cleaning Procedures

Clean the Bore

- After one pull, take the handle off, and repeat the process.
- If the bore brush begins to tighten after a few pulls, loosen it up and repeat the process.
- Send a cleaning patch dampened with bore cleaning solvent through the bore occasionally to help clean out the debris the brush has loosened up.

NOTE: Always have the bore wet with cleaner before trying to pull a brush through.

Disassembly of Bolt Carrier Assembly

- To disassemble the bolt carrier assembly, first remove the firing pin retaining pin from the side of the carrier. Next, allow firing pin to fall out of bolt and carrier. Now you can remove the cam pin (1/4 turn then lift) and then the bolt will pull straight out.
- Clean the bolt carrier assembly and components with a suitable cleaning solvent and remove any built-up carbon on the bolt.
- Re-assembly is the reverse of disassembly. Install the bolt into the carrier and install the cam pin. **Note: The cam pin will only go into the bolt one way, if the pin will not go in, rotate the bolt 180 degrees and it should slide in freely.**
- Install the firing pin followed by the firing pin retaining pin. **CAUTION: Failure to install the firing pin correctly may cause the gun to fire with the bolt open and could cause serious injury or death.**
- The cam pin and gas rings can be lightly lubricated with a lightweight gun oil.
- When assembling the bolt, to reduce gas loss, stagger the three gas ring gaps 120 degrees apart around the bolt.

Inspection Before Lubricating

- **Check the bolt:** Look for fractures or cracks. Pay close attention to the cam pin hole area. Bolts with any pitting that extends into the firing pin hole should be replaced.
- **Check the firing pin:** If the firing pin is bent, cracked or too sharp, it should be replaced.
- **Check the firing pin retaining pin:** If it is bent or badly worn, it should be replaced. **CAUTION:** **NEVER** use a “Cotter Pin” as a replacement for a real firing pin retaining pin. Cotter pins are not made of suitable materials, and the round head shape will cause damage.
- **Check the cam pin:** If cam pin is chipped or cracked it should be replaced.
- **Check the extractor and the extractor spring:** If the extractor is chipped, or has broken edges in the area of the lip that engages the cartridge rim, it should be replaced.

Lubrication

Upper and Lower Receivers:

NOTE: The components in the lower assembly (fire Control) operate the best and will have the best longevity if kept clean but dry. Lubrication is neither necessary or helpful. The lower assembly can be washed /rinsed in soap and water, or sprayed clean with a reasonably fast drying oil free solvent type cleaner.

Lightly Lubricate

- Lightly lubricate the inside of the upper receiver, bore and chamber using a cleaning rod and patch.
- Lightly lubricate the firing pin.
- Lightly lubricate the charging handle and the inner and outer surfaces of the bolt carrier.

Generously Lubricate

- The bolt, cam pin area, and bolt gas rings.
- The carrier key should be dried with a pipe cleaner, then add one drop of lubricant.

Troubleshooting

Problem:

Check For:

What To Do:

Won't Fire

Selector lever on Safe

Put it on FIRE

Improper assembly of firing pin retaining pin

Assemble correctly; goes in back of large shoulder on firing pin

Too much oil in firing pin recess

Wipe out excess with pipe cleaner

Defective ammunition

Remove and discard

Too much carbon on firing pin or in firing pin recess

Clean

Won't Extract

Broken extractor spring

See a qualified gunsmith

Dirty or corroded ammo

Remove stuck round - push out with cleaning rod

Carbon in chamber

Clean chamber

Troubleshooting

Won't Extract

Fouling or carbon in extractor recess or lip	Clean extractor
Frozen extractor	Remove & clean
Restricted movement of bolt carrier group	Remove, clean, & lube. (before putting bolt back in, make sure gas tube fits into carrier key and that the carrier moves freely).

Won't Chamber

Damaged ammo	Replace
Carbon in chamber or on gas tube	Clean
Dirty or corroded ammo	Clean or replace

Won't Lock

Dirt, corrosion, or carbon buildup in barrel locking lugs	Clean lugs
---	------------

Troubleshooting

Won't feed

Dirty or corroded ammo Clean or replace

Dirty magazine Clean

Defective magazine Replace

Too many rounds in magazine Remove excess

Magazine not fully seated Adjust magazine catch: turn catch clockwise to tighten and counter clockwise to loosen

Double Feed

Defective magazine Replace

Bolt won't unlock

Dirty or burred bolt Clean or see a qualified gunsmith

Troubleshooting

Short Recoil

Cleaning materials stuck inside carrier key Clean out if possible or have firearms checked by a qualified gunsmith

Worn gas rings Replace gas rings

Underpressured ammunition Use factory new ammunition

Carbon or dirt in carrier key or on outside of gas tube Clean carrier key or key area of gas tube

Bolt Fails to Lock After Last Round

Dirty or corroded bolt catch Replace

Faulty magazine Replace

Short recoil See Above

Please Practice Safe Firearms Handling

This Owner's Manual should always accompany this firearm. When you lend, give, or sell this firearm, be sure this manual goes with it.



IMPORTANT NOTICE: Any modifications of any kind, including any addition or removal of components or disassembly beyond what is detailed in the owner's manual could completely **VOID YOUR WARRANTY!**

IMPORTANT NOTICES

CAUTION: Because New Frontier Armory manufactures bolts, barrels, receivers, and other firearm components in a variety of calibers always be sure to use the proper ammunition and magazines for the bolt and barrel combination installed on your firearm.

Limited One Year Warranty

New Frontier Armory products are warranted to be free from defects in materials and workmanship for one year and ten days from the date of purchase.

To initiate a warranty request, contact New Frontier Armory at www.newfrontierarmory.com/warranty

All warranty claims should state the model and serial number of the gun, a description of the difficulty experienced, and the date of purchase. It is recommended that shipment be insured by the owner, since New Frontier Armory will not accept responsibility for loss or damage in transit. Shipping and insurance costs for return of firearm or components to owner will be paid by New Frontier Armory if the work being completed is covered under this warranty.